

KIT CONTENTS:

ITEM 1 - LH Phoenix Seat End
ITEM 2 - RH Phoenix Seat End
ITEM 3 - Metal Support Brace
ITEM 4 - Straight Seat Slat
ITEM 5 - Washer M10
ITEM 6 - Screw M10 x 70mm
ITEM 7 - Bullnose Seat Slat
ITEM 8 - Screw M10 x 60mm
ITEM 9 - Nyloc Nut M10
ITEM 10 - Rear Metal Tie Bar
ITEM 11 - Cover Cap Outer
ITEM 12 - Washer M12
ITEM 13 - Cover Cap Inner
ITEM 14 - Fixing Cover Cap

EQUIPMENT REQUIRED:

- 17mm Socket
- Socket Driver
- Socket Extension

x 1 x 1

х 1

x 1 x 18 x 10 x 4 x 5 x 5 x 5

x 1

x 2 x 2 x 2 x 2 x 15 - Lump Hammer / Nylon Faced Hammer x 1


Assembly requires a minimum of 2 x people




x 2

x 2

х1






Stand Items 1 and 2 upright spaced approximately 1.5m apart with the base fixing lugs facing inwards (as shown). Slot Item 3 on top of both Seat Ends. The Support Brace locates into indentations in the tops of the Seat Ends. Take care to ensure the holes in the Support Brace align with the fixing holes in the Seat Ends and that the Support Brace is facing forwards as shown.

STEP 2


Place Item 4 on top of the Support Brace, aligning the holes in the Slat with the holes in the Support Brace and threaded hole in the Seat Ends. Place Item 5 onto Item 6. Place the assembled fixing through the Seat Slat, Support Brace and into the threaded hole in the left hand Seat End (Item 1). Tighten the fixing loosely by hand. Repeat this STEP to affix the Slat to the right hand Seat End (Item 2).



Place 2 x Item 7's onto the Seat Ends either side of the Slat fitted during STEP 2 with one of the 'bullnosed' ends facing forwards and other facing backwards (as shown). Assemble 4 x fixings by placing Item 5 onto Item 6. Place the fixings through the fixing holes in the Bullnose Slats and tighten the fixings loosely by hand.

STEP 4


Assemble 3 x 60mm fixings by placing 3 x Item 5's onto Item 8's. Place the fixings through the middle fixing holes of the 3 x Seat Slats and down through the Support Frame. Fit Item 5 followed by Item 9 onto the screw threads on the underside of the Support Frame. Loosely tighten the nuts by hand for now.




Assemble 4 x fixings by placing Item 5's onto Item 6's.

Place 1 x Item 7 (with bullnose facing downwards) against the backrest part of the Seat Ends. Align the holes in the Slat with the lower set of fixing holes in the Seat End. Place the assembled fixing through the Slat and into the threaded hole in left hand Seat End. Tighten the fixing loosely by hand. Assemble another fixing and affix the Slat to the right hand Seat End in the same manner.

Fit the remaining Item 7 to the Seat End in the same manner as the Slat just fitted (this time with the bullnose of the Slat facing upwards).



Assemble 2 x 60mm fixings by placing 2 x Item 5's onto Item 8's. Place the fixings through the middle fixing holes of the 2 x backrest Slats. On the back side of the Slats fit Item 10 over the fixing threads followed by 2 x Item 11's. Secure the fixings in place by adding Item 11 followed by Item 9 onto the screw threads. Loosely tighten the nuts by hand.



Tighten the middle set of five fixings first using the pair of sockets (or socket and spanner) ensuring the Slats are evenly spaced as you do so. Take care not to overtighten the middle pair of fixings in the Backrest as this may cause damage to the plastic Cover Caps. Then tighten the fixings attaching the Seat Ends to the Slats again ensuring the slats are evenly spaced before tightening fully.

STEP 8

Use a nylon faced hammer or mallet to tap into place all of the Fixing Cover Caps (Item 14) over each of the heads of the fixings on show. Press both Item 13's into Item 12's.

ASSEMBLY COMPLETE

IMPORTANT NOTE: PLEASE ENSURE THAT ALL RELEVANT PERSONNEL READ THE POINTS LISTED WITHIN THIS LEAFLET AND THAT A COPY IS GIVEN TO STAFF INVOLVED WITH THE INSTALLATION AND MAINTENANCE OF THIS PRODUCT. SAFETY NOTE: PLEASE REFER TO 'THE MANUAL HANDLING OPERATIONS REGULATIONS 1992' DURING HANDLING.

> Glasdon and phoenix are trademarks or registered trademarks of glasdon group or its SUBSIDIARIES IN THE U.K. AND OTHER COUNTRIES

- A planned maintenance schedule or regular inspection is
- recommended, replacing components as necessary. • Replacement components are available direct from GLASDON.
- GLASDON cannot be held responsible for claims arising from incorrect installation, unauthorised modifications or misuse of the product. Stock No. C000/0505 - DWG No. 09B-025-31 Issue 1 - August 2017
- © Copyright AUG 2017
- Glasdon UK Ltd reserve the right to alter specifications without prior notice.



Glasdon U.K. Limited Preston New Road BLACKPOOL Lancashire FY4 4UL Tel.: 01253 600410 Fax : 01253 792558 e-mail: sales@glasdon-uk.co.uk web: www.glasdon.com