

RETRIEVER 35™ CHUTE-LOCK FITTING INSTRUCTIONS

NOTE: Ensure that all relevant personnel read the points listed below and that a copy is passed on to staff involved with the installation. Please also refer to the 'Manual Handling Operations Regulations 1992' during the handling of the product and materials used for installation.

KIT CONTENTS:

ITEM 1. Installation Template	x 1
ITEM 2. Self-tapping Screw	x 4
ITEM 3. L Bracket	x 2
ITEM 4. Allen Key	x 1
ITEM 5. Stopper Bar	x 1

TOOLS REQUIRED FOR INSTALLATION:

- Hand Drill
- 2mm Drill Bit

FITTING:

1. Open the lid and keep chute in the closed position.
2. Place the Template (Item 1) firmly against the lower edge of the chute and drill 4 holes into the lid with the 2mm drill bit (Fig.A).
3. Line up the 2 upper holes of one L Bracket (Item 3) with the holes on the right hand side of the lid, ensuring that the single hole faces left (Fig.B).
4. Using the Allen Key (Item 4) screw into place with 2 Self-tapping Screws (Fig. B).
5. With the chute still closed slide the Stopper Bar (Item 5) into the single hole of the first bracket (see Fig.C).
6. Line the second L Bracket up with the holes on the left, facing the single hole to the right, and hold in place. Slide the Stopper Bar left into the single hole, ensuring that it moves freely through both L Brackets and that the chute is tightly secured (Fig.C).
7. Now fasten the left L Bracket with the 2 remaining Self-tapping Screws (Fig.D).

LOCKING & UNLOCKING:

8. The chute cover is now locked in the closed position. To unlock simply slide the Stopper Bar to one side and twist out. Please ensure that when not in use the Stopper Bar is stored inside the bin or in a secure location for future use.

