

NEXUS™ 50 REAR POD RETROFIT INSTRUCTIONS

NOTE: Ensure that all relevant personnel read the points listed below and that a copy is passed on to staff involved with the installation. Please also refer to the 'Manual Handling Operations Regulations 1992' during the handling of the product and materials used for installation.

KIT CONTENTS:

ITEM 1. Installation Template	x 2
ITEM 2. M5 Screw	x 4
ITEM 3. Pod Sleeve	x 1
ITEM 4. Reservoir/Liner	x 1
ITEM 5. Pod Lid	x 1

TOOLS REQUIRED FOR INSTALLATION:

- Pencil
- Hand Held Drill
- 5mm Drill Bit
- Pozi or Phillips Head Screw Driver

FITTING:

1. Punch out the 4 holes marked on the templates (Item 1) and fold the tabs along the dotted lines (Fig. A).
2. Locate Template 1 as shown in Fig. B. The three bottom tabs should fit around the two protruding sack retention stubs and the top tab should fit into the recess by the handle. Hold the template firmly in place and mark the two holes.
3. Locate Template 2, as shown in Fig. B, ensuring that the circle in the back of the Nexus 50 lines up with the top of the arc in the template. Hold firmly and mark the two holes.
4. Remove the templates and drill the 4 marked holes with a 5mm drill bit.
5. Remove the door of the Nexus 50 and line up the Pod Sleeve (Item 3) as shown in Fig. C. Using the 4 Screws supplied (Item 2) secure the Pod Sleeve from inside the Nexus 50.
6. The Reservoir or Liner (Item 4) can now be inserted into the Pod and the Pod Lid (Item 5) snapped on top to complete the assembly (Fig. D).

