

C-Thru Bin™ Blanking Flap


OPERATING INSTRUCTIONS

IMPORTANT NOTE:- ENSURE THAT ALL RELEVANT PERSONNEL READ THE POINTS LISTED BELOW AND THAT A COPY IS PASSED ON TO STAFF INVOLVED WITH THE INSTALLATION.







lock. (Do not turn the key.) This will automatically release the locking mechanism.




resting on the bin body, allowing access

to the underside







With the key still in position, turn hood anti - clockwise, then lift hood off. blanking off the bins opening.

- A planned maintenance schedule of regular inspection is recommended, replacing components as necessary.
- Replacement components are available direct from GLASDON.
- GLASDON cannot be held responsible for claims arising from incorrect installation, unauthorised modifications or misuse of the product.

Issue 1 August 2011 Stock no. C000/0394 Copyright May 2005.


Glasdon reserve the right to alter specification without prior notice.

SGIASON AND C-THRU BIN ™ ARE TRADEMARKS OR REGISTERED TRADEMARKS OF GLASDON GROUP OR ITS SUBSIDIARIES IN THE U.K. AND OTHER COUNTRIES




Glasdon U.K. Limited Preston New Road BLACKPOOL Lancashire ® FY4 4UL

(01253) 600410 (01253) 792558 e-mail: sales@glasdon-uk.co.uk web: www.glasdon.com



With the key still in position, offer the hood onto the body aligning with the rear bobbin. When aligned turn hood clockwise then remove key.



To open the flap return to step 3 and turn the knob 90 degrees as shown until the flap falls open.