


ELECTRA™ RECYCLING BIN

OPERATOR INSTRUCTIONS


IMPORTANT NOTE: PLEASE ENSURE THAT ALL RELEVANT PERSONNEL READ THE POINTS LISTED WITHIN THIS LEAFLET AND THAT A COPY IS GIVEN TO STAFF INVOLVED WITH THE INSTALLATION AND MAINTENANCE OF THIS PRODUCT

SAFETY NOTE: PLEASE REFER TO 'THE MANUAL HANDLING OPERATIONS REGULATIONS 1992' DURING HANDLING.

To Open.




1. Using the triangular-shaped key provided, turn the key anti-clockwise to unlock the door.




2. The door is fitted with a magnetic strip therefore a little force is required when opening.

To Empty and Replace Solid Liner.




3. Slide the liner out of the bin by pulling on the liner handle.




4. Lift the liner inside the bin and rest it on the internal shelf using the liner handle.


To Secure a Sack in Position (Sack Retention Model).



5. Pull the sack retention system forwards.



6. Pull the rear sack band upwards.




7. Insert the sack down through the sack bands.

ELECTRA™ RECYCLING BIN


OPERATOR INSTRUCTIONS

IMPORTANT NOTE: ENSURE THAT ALL RELEVANT PERSONNEL READ THESE INSTRUCTIONS PRIOR TO USE


To Close.



8. Fold sack over the bands. Press the rear sack band downwards to secure.



9. Push the sack retention system back inside the bin.



10. Close the door. Using the triangular key, turn it clockwise to lock the bin.

SAFETY NOTE: MINIMUM OF TWO PERSONNEL REQUIRED TO HANDLE THE 120L & 170L UNITS


To Assemble the Freestanding Base (60L/120L Model).

KIT CONTENT


ITEM 1 - Free Standing Base Kit	x1
ITEM 2 - M10 Screw	x4
ITEM 3 - M10 Washer	x4
ITEM 4 - M10 Nut	x4

TOOLS REQUIRED


17mm Spanner / Socket x 1



11. Place the Electra Litter Bin on the Free Standing Base and align holes in the base of the bin with the four protruding screws.



12. Secure and tighten the M10 washer [ITEM 3] and M10 Nut [ITEM 4] in position using 17mm Spanner.



13.

ELECTRA™ RECYCLING BIN

INSTALLATION INSTRUCTIONS - EXISTING CONCRETE FOUNDATION/PAVING

IMPORTANT NOTE: ENSURE THAT ALL RELEVANT PERSONNEL READ THESE INSTRUCTIONS PRIOR TO USE
SAFETY NOTE: MINIMUM OF TWO PERSONNEL REQUIRED TO HANDLE THE 120L & 170L UNITS

To Install the Litter Bin (Ground Fixing).

KIT CONTENTS:

ITEM 1 - Anchor Rawl Plug x 4

ITEM 2 - Screw (M10 x 60mm) x 4

ITEM 3 - M10 x 50mm Washer x 4

TOOLS REQUIRED:


Marker Pen

Drill with Ø16mm Masonry Drill Bit


Hammer

17mm Socket Set or 17mm Spanner

Lubricant or Grease



Position bin onto concrete foundation/paving ensuring the fixing hole is a minimum of 110mm from the edge and the concrete is in good condition.




Orientate the bin and mark the hole positions.




Move the bin aside. Ensure the hole markings are clearly visible.




Drill four holes using a 16mm masonry drill to a minimum depth of 80mm. Remove concrete dust from holes with an air blower/brush.




Using a hammer, gently tap the four Anchor Rawl Plugs (ITEM 1) into the ground fixing holes.



Place the bin back into position. Take care to align the ground fixing holes.



Take the M10 Screws (ITEM 2) and Washers (ITEM 3) and fit them through the base of the bin and into the ground anchor sleeves fitted into the concrete.



Tighten the M10 Screws using a Socket Wrench fitted with a 17mm Socket or Spanner (maximum recommended torque setting is 40Nm).

ELECTRA™ RECYCLING BIN

INSTALLATION INSTRUCTIONS - NEW CONCRETE FOUNDATION

IMPORTANT NOTE: ENSURE THAT ALL RELEVANT PERSONNEL READ THESE INSTRUCTIONS PRIOR TO USE
SAFETY NOTE: MINIMUM OF TWO PERSONNEL REQUIRED TO HANDLE THE 120L & 170L UNITS


To Install the Litter Bin (Concrete-In).

KIT CONTENTS:


ITEM 1 - Adjustable Depth Concrete-in Fixing	x 4
ITEM 2 - M10 x 50mm Washer (Zinc Plated)	x 4
ITEM 3 - M10 Wing Nut	x 8
ITEM 4 - Screw (M10 x 100mm)	x 4
ITEM 5 - M10 x 50mm Washer (Stainless)	x 4

TOOLS REQUIRED:

Equipment to excavate hole.
Concrete Mix.
Spirit Level.
17mm Socket Set or 17mm Spanner.
Lubricant or Grease.




22.
Lay the bin on its back (onto a soft surface). Attach the four concrete fixings (ITEM 4) through the ground fixing holes as shown. Use a 17mm Spanner or Socket Wrench to secure.




23.
Prepare a hole.

- Electra 60L- 500mm(L) x 350mm(W)
- Electra 85L- 500mm(L) x 500mm(W)
- Electra 120L - 1000mm(L) x 350mm(W)
- Electra 170L - 1000mm(L) x 500mm(W)


Fill the base with an 80mm deep layer of fine gravel. Place support blocks under the positions where the concrete fixings will rest at the base of the hole.




24.
Position bin in the hole and adjust the blocks/gravel so the bin base rests at ground level.




25.
Use a spirit level to check bin is vertically & horizontally level.



26.
Pour in the concrete mix to the desired level.



27.
Wipe away any excess concrete around the base.

 **Glasdon** AND ELECTRA ARE TRADEMARKS OR REGISTERED TRADEMARKS OF GLASDON GROUP OR ITS SUBSIDIARIES IN THE U.K. AND OTHER COUNTRIES

- A planned maintenance schedule or regular inspection is recommended, replacing components as necessary.
- Replacement components are available direct from GLASDON.
- GLASDON cannot be held responsible for claims arising from incorrect installation, unauthorised modifications or misuse of the product.

Stock No. C000/0500 - DWG No. 07B-354-70 Issue 1 - May 2017

© Copyright MAY 2017

Glasdon UK Ltd reserve the right to alter specifications without prior notice.



Glasdon U.K. Limited

Preston New Road
 BLACKPOOL
 Lancashire FY4 4UL
 Tel. : 01253 600410
 Fax : 01253 792558
 e-mail: sales@glasdon-uk.co.uk
 web: www.glasdon.com